

Abb./Fig. 1



Abb./Fig. 2



Abb./Fig. 3


Abb./Fig. 4

INSTRUCTIONS/ANLEITUNG
ZERO STOP

DE

Schießen Sie das Gewehr auf die gewünschte Nullpunktentfernung ein. Schrauben Sie die flache Abdeckkappe des Turms auf der Oberseite des Turms (Abb. 1) ab. Entfernen Sie den Turm (Abb. 2). Lösen Sie mit einem Inbusschlüssel die 3 silbernen Schrauben auf dem Messingring (Abb. 3). Drücken Sie den Messingring nach unten, bis er die Messinggrundplatte berührt.
Hinweis: Die schwarze Schraube am hervorstehenden Knopf nicht herausdrehen!
Bewegen Sie den Messingring gegen den Uhrzeigersinn für CCW-Türme und im Uhrzeigersinn für CW-Türme bis zur Anschlagmarkierung (Abb. 4).
Ziehen Sie die 3 Schrauben wieder fest.
Setzen Sie den Turm auf die Nullmarke und schrauben die flache Abdeckkappe wieder auf (Abb. 2).

EN

Sight your rifle to the desired zero-stop distance. Unscrew the flat screw cap of the turret on the top of the turret (Fig. 1). Remove the turret (Fig. 2). Using an allen wrench, loosen the 3 silver screws on the brass ring (Fig. 3).
Note: Don't unscrew the black screw on the protruding knob!
Push the brass ring down until it touches the brass base plate.
Move the brass ring counterclockwise for CCW turrets and clockwise for CW turrets to the stop mark (Fig. 4).
Retighten the 3 silver screws. Return the tower ring to the zero mark and tighten the flat screw cap of the tower (Fig. 2).

WWW.GP-OPTICS.COM